z71xx_ifu.qxp 2005.11.11. 11:37 Page 2

Thank you for choosing an Electrolux Cycloniclite vacuum cleaner. These operating instructions cover all Cycloniclite models. This means that with your specific model, some accessories may not be included.

Accessories and safety precautions	3
Before starting	4
Getting the best results	4
Removing the contents of the dust container	5
Replacing the motor filter	5
Replacing the micro filter	5
Cleaning the cartridge filter	5
Cleaning the hose and the nozzle	6
Troubleshooting and customer information	7
Electrical supply instructions	8
WARNING instructions	9
Guarantee	10

z71xx_ifu.qxp 2005.11.11. 11:37 Page 3



Accessories

1. Cartridge filter
2. Protector mesh
3. Metal extension tubes
4. Hose
5. Hose handle with suction control
6. Dual purpose floor nozzle
7. Turbo nozzle (Z7120)
8. Upholstery nozzle with plush plate
9. Crevice nozzle
10. Dusting brush
11. Caddy

Safety precautions

The Cycloniclite should only be used by adults for normal vacuuming in a domestic environment. The vacuum cleaner features double insulation and does not need to be earthed.

Never vacuum:

- In wet areas
- Close to flammable gas, etc.
- Without filters (this may damage the cleaner). A safety device is fitted which prevents the dust container closing without a cartridge filter in place. Do not attempt to force the dust container shut.

Never vacuum:

- Sharp objects
- Fluids (this can cause serious damage to the machine)
- Hot or cold cinders, lit cigarette butts, etc.
- Fine dust from plaster, concrete, flour or ash, for example.

The above can cause serious damage to the motor - damage which is not covered by the warranty.

Electrical cable precautions:

- A damaged cable must be replaced by an authorised Electrolux service engineer. Damage to the cleaner cable will not be covered by the warranty.
- Never pull or lift the vacuum cleaner by the cable.
- Disconnect the plug from the mains before cleaning or maintenance of the vacuum cleaner.
- Regularly check that the cable is not damaged. Never use the vacuum cleaner if the cable is damaged.

All service and repairs must be carried out by an authorised Electrolux service engineer. Always keep the vacuum cleaner in a dry place.



BEFORE STARTING

1. Always operate the cleaner with the dust container installed.
2. Always operate the cleaner with the filter set property installed.
3. Insert the hose until the catch clicks to engage (press the catch to engage hose).
4. Attach the metal extension tubes to the hose handle and the floor nozzle.

5-6. Pull out the cable and plug it in. Press the foot pedal to rewind the cable (take hold of the plug to prevent it striking you).

7. Press the On/Off button with control your foot to start the vacuum cleaner. Adjust the suction power by using or the suction control on the hose handle.

GETTING THE BEST RESULTS

Hard floors: Use the dual purpose floor nozzle with the left pedal in position (8.)

Carpets: Use the dual purpose floor nozzle with the left pedal in position (9.)

Turbo nozzle: Use the turbo nozzle to remove pet hairs and other stubborn fibres (Z7120).

Reduce suction power for rugs and fabrics.

Upholstered furniture: Use the upholstery nozzle.

Skirting boards, crevices, corners, etc.: Use the crevice nozzle.

Above the floor surfaces and some upholstered furniture: Use the dusting brush.



REMOVING THE CONTENTS OF THE DUST CONTAINER
Always operate the cleaner with the dust container installed.

1. Remove the dust container by using the open button on the handle.
2. Remove the filter set by pushing the button.
3. Remove the contents of the dust container.
2. Insert the filter set back into the dust compartment.
1. Insert the dust container back into the cleaner by pressing it down until it clicks.

Note: Empty the dust container even if it is not full (the filters may be blocked). Also replace after using carpet-cleaning powder.

REPLACING THE FILTERS
Filters should be replaced twice a year.
Disconnect from electrical outlet before cleaning filters.
Your cleaner is fitted with an electronic filter indicator. Before commencing cleaning, without the hose attached, check the filter indicator. If illuminated, clean or replace filter, if not, attach the hose, extension tubes and accessories as normal and continue cleaning.
NB: It is normal for the indicator light to illuminate during cleaning

Replacing the motor filter
1. Remove the dust container by using the open button on the handle.
2. Remove the filter set by opening the button.
4. Remove the filter with grill from its holder.
5. Remove the filter from the grill, and put a new one into it.
4. Put the filter with grill back into its place.

Replacing the micro filter
6. Open the filter grill to remove the exhaust filter.
Take the filter out of its place.
Put a new filter into its place, then close the filter grill.
Motor and microfilter reference number: **EF75**

Replacing or cleaning the cartridge filter
1. Remove the dust container by using the open button on the handle.
2. Remove the filter set by pushing the button.
7. Remove the protector mesh from the cartridge filter by pulling it out (A).
8. Remove the cartridge filter by turning it counter-clockwise (A) and pull it out (B).
9. Shake the dirt from the filter and the mesh into a bin, if necessary the filter and mesh can be rinsed, with cold water, under a tap.
10. Air dry them for approximately 24 hours, to ensure it is completely dry before re-using. Avoid direct sunlight and extreme drying circustances.

If you wish to use your appliance while the cartridge filter is drying, you may use the extra cartridge filter inserted in the packaging box (Z7109, Z7110, Z7119).

8. Insert the cartridge filter into its place (B) and turn it clockwise (A).
7. Insert the protector mesh into its place by pushing it onto the cartridge filter (B).
2. Insert the filter set back into the dust container.
1. Insert the dust container back into the cleaner by pressing it down until it clicks.

Cartridge filter reference number: **EF75b.**

Note: Do not use cleaning agents and avoid touching the delicate filter surface.

z71xx_ifu.qxp 2005.11.11. 11:37 Page 6



1



2



3

CLEANING THE HOSE AND NOZZLE

The vacuum cleaner stops automatically if the nozzle, tube or hose becomes blocked, or the filters are blocked. Disconnect from the mains and allow the vacuum cleaner to cool down for approximately 20-30 minutes. Clear whatever is causing the blockage and/or replace dirty filters.Then restart the vacuum cleaner.

Tubes and hose

1. Use a cleaning strip or similiar to clear the tubes and hose.
2. It is sometimes possible to clear the hose by "massaging" it. However, be careful in case the obstruction has been caused by glass or needles caught inside the hose.

Note: The warranty does not cover any damage to hoses caused by cleaning them.

Cleaning the floor nozzle

3. To avoid reduction in suction power, frequently clean the dual purpose floor nozzle. The easiest way to clean it is by using the hose handle.

z71xx_ifu.qxp 2005.11.11. 11:37 Page 7

Troubleshooting

The vacuum cleaner does not start

1. Check that the cable is connected to the mains.
2. Check that the plug and the cable are not damaged.
3. Check for a blown fuse.

The vacuum cleaner stops

1. Check whether the dust container is full. If so, empty it.
2. Is the nozzle, tube or hose blocked?
3. Are the filters blocked?

Water has entered the vacuum cleaner

It will be necessary to replace the motor by an authorised Electrolux service engineer.
Damage to the motor caused by the penetration of water is not covered by the warranty.

Customer Information

Electrolux decline all responsibility for all damages arising from any improper use of the appliance or in cases of tampering with the appliance.
This product is designed with the environment in mind. All plastic parts are marked for recycling purposes.
For further details see our website: www.electrolux.com

For repairs or accessories, contact the Electrolux Group Floorcare Helpline on 08706 055 055.

If you have any comments on the cleaner or the Instructions for Use booklet please e-mail us at: floorcare@electrolux.com

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, whic could otherwise be caused by inapprprate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

z71xx_ifu.qxp 2005.11.11. 11:37 Page 8

ELECTRICAL SUPPLY INSTRUCTIONS

Before you start ...check the voltage

Before connecting the cleaner to an electrical supply ensure that voltage marked on the data plate (on the underside of cleaner) is correct for your electrical supply. If is not, do not use the cleaner but refer back to your dealer.



Connecting to your electrical supply

Permanently connected to the cleaner is a mains supply (2-core) cable fitted with a non-rewirable plug incorporating a 13A fuse. In the event of the fuse requiring replacement the fuse cover should be removed using a small screwdriver. The old fuse MUST be replaced by a 13A ASTA approved BS1362 fuse and the fuse cover must be replaced before the plus is used again. In the event of loss of the fuse cover, replacements can be obtained from your Electrolux dealer or Electricity Board and must be of the same colour as indicated by the coloured insert on the base plug.

If difficulty is experienced in obtaining a replacement, contact your nearest Electrolux Service Centre. (Please see the separate Electrolux Service Organisation leaflet).

In no circumstances must the plug be used without a correct fuse cover fitted.

If the plug that is fitted to your appliance is not suitable for your socket outlet, it must be cut off and the appropriate plug fitted. Remove the fuse from the cut off plug. The cutoff plug should then be disposed of to prevent hazard of shocks in case it should be plugged into a 13 Amp socket in another part of your home

The wires in the mains cable of this appliance are coloured in accordance with the following code:

Blue: Neutral.
Brown: Live.

As the colours of the wires in the mains cable of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured blue must be connected to the terminal which marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked the letter L or coloured red.

If using a three-pin plug, do not make any connection to the terminal marked with the letter E or by the earth symbol or coloured green or green-and-yellow. This cleaner is double insulated and no earth-connection is necessary.]

It is in you interest to ensure that the plug is correctly attached to the mains cable. In case of doubt, have it done by a qualified electrician, as Electrolux cannot regard the repair of faults on the plug connection as a service that can be given free of charge under the terms of guarantee.

As a general guide to fitting any plug

- Ensure the lengths of wire inside the plug are prepared correctly.
- Connection should be firmly made after all conductor stands are entered into the terminal posts.
- When preparing the cable ends take care not to damage the outer seal, or insulation surrounding the inner conductors.
- Tighten all screws.
- Replace the top cover of the plug and secure.

z71xx_ifu.qxp 2005.11.11. 11:37 Page 9

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL THE INSTRUCTIONS BEFORE USING THIS VACUUM CLEANER.

WARNING

To reduce the risk of fire, electric shock, or injury:

- Do not use out doors or on wet surfaces.
- Do not leave vacuum cleaner when plugged in.
- Do not allow to be used as a toy. Close attention is necessary when used near children. Do not allow children to operate this appliance.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If vacuum cleaner is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service centre before using.
- Do not pull or carry by cord, use cord as a handle, close door on cord. Keep cord away from heated surfaces.
- Do not use extension cords or outlets with inadequate current carrying capacity.
- Turn off all controls before unplugging.
- Do not unplug by pulling on cord. To unplug, grasp the plug not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any opening block, keep free of dust, lint, hair and anything that may reduce air flow.
- Do not use to pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.
- Do not use without dust container in place.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.
- Store your cleaner indoors in a cool, dry area.
- Keep your work area well lighted.
- Unplug electrical appliances before vacuuming them.

SAVE THESE INSTRUCTIONS

z71xx_ifu.qxp 2005.11.11. 11:37 Page 10

GUARANTEE

This guarantee is in addition to your statutory and other legal rights.

Electrolux products are carefully designed, manufactured, tested and inspected and in consequence, we undertake to replace or repair any part found to be defective in material or workmanship, within one year of delivery to the original purchaser, free of charge. You may be required to take the product to your nearest service provider if the product requries attention during the first year.

There are certain conditions which may invalidate this guarantee:

a. It is dependent upon the appliance being correctly installed and used in accordance with the Company's instructions under normal domestic conditions within the United Kingdom or the Republic of Ireland.

b. Service at all times must be carried out by an Electrolux Service Representative or authorised agent.

c. The guarantee may be invalidated by unauthorised repair or modification of the appliance.

d. You may be charged by the Electrolux Group if you call for an engineer to resolve a problem that we believe is covered in the instruction booklet.

The Company does not accept liability for defects arising from neglect, misuse or accident. This guarantee excludes such normal wearing parts as filters, brushes and dust bags as the life of these depends upon the amount and nature of use.

Proof of the date of purchase will be required before service under guarantee is provided.

For futher assistance call the
Electrolux Group Floorcare Helpline on 08706 055 055.

Important:
For future reference we suggest you record the following details here, and keep the receipt with this booklet as proof or purchase.

Purchased from: _____

Date purchased _____Model No _____

Electrolux

The Electrolux Group, 101 Oakley Road, LUTON, BEDFORDSHIRE, LU4 9QQ

Features of the Electrolux vacuum cleaner and accessories with it are protected in Great Britain and abroad by Patents of Registered Designs.

This appliance conforms with the requirements of the amended E.E.C. directive No. 89/336/EEC relating to electromagnetic compatibility (EMC) CE.

The Electrolux Group may introduce modifications to their product from time to time, and consequently the details given in this booklet are subject to alteretion without notice.

T4501 02 01 06